

Quick Reference Guide



• Buttons

- Power button, hold for 2 seconds to power on
- Power button, hold for 5 seconds to power off
- Large button on top, hold for 2 seconds (until vibration felt) to send an alarm

• Device States

- Powering on (rapid vibrations and flashing green light)
- Powering off (long vibration and solid red light)
- Powered on (rapid blue flashing light twice every 2.5 seconds)
- Charging (slow flashing green light every 5 seconds)
- Charging error (solid red light)
- Fully charged (solid green light)
- Low battery (rapid red flashing light 3 times every 3 seconds)
- Network coverage problem (slow red flashing light twice every 5 seconds)

***Charging states override other states**



Alarm / Panic button

Hold down the big button on top to the device for 2 seconds to send an alarm message to control, who will then action accordingly.



No motion events.

Used to detect when users do not move for an extended period, which then automatically activates an alarm.




Small casing

New modern design, small casing with big capacity battery – 800mAh. Dimensions only 44x43x20 mm, Weight 40g.



Certified IP67 case

The TMT250 features a waterproof (IP67) case design which ensures increased protection against dust and water ingress.



Accelerometer & Gyroscope

In-built accelerometer & gyroscope provides higher accuracy positioning, no movement events and allows the device to go into a sleep state to extend battery life.